

Coast Guard, DHS

§ 117.41

requests submitted less than 90 days before a needed change if those requests can be processed before the date of the needed change.

(d) *Determination.* The District Commander's determination to allow the schedule change is normally forwarded to the bridge owner within ten working days after receipt of the request. If the request is denied, the reasons for the denial will be set out in the District Commander's decision letter.

(e) The drawbridge must return to its regular operating schedule immediately at the end of the designated time period.

(f) If the authorized closure period for an event is broken into separate time periods on the same day or on consecutive days, the drawbridge must provide openings for navigation between the authorized closures.

(g) The District Commander will also announce the change to the operating schedule in the Local Notice to Mariners and other appropriate local media.

[USCG–2001–10881, 71 FR 70308, Dec. 4, 2006]

§ 117.36 Closure of drawbridge for emergency repair.

(a) When a drawbridge unexpectedly becomes inoperable, or should be immediately rendered inoperable because of mechanical failure or structural defect, the drawbridge owner must notify the District Commander of the closure without delay and give the reason for the emergency closure of the drawbridge and an estimated time when the drawbridge will be returned to operating condition.

(b) The District Commander will notify mariners about the drawbridge status through Broadcast Notices to Mariners, Local Notice to Mariners and any other appropriate local media.

(c) Repair work under this section must be performed with all due speed in order to return the drawbridge to operation as soon as possible.

[USCG–2001–10881, 71 FR 70308, Dec. 4, 2006]

§ 117.39 Authorized closure of drawbridge due to infrequent requests for openings.

(a) When there have been no requests for drawbridge openings for at least two years, a bridge owner may request

in writing that the District Commander authorize the drawbridge to remain closed to navigation and to be untended.

(b) The District Commander may:

(1) Authorize the closure of the drawbridge;

(2) Set out any conditions in addition to the requirement in paragraph (d); and

(3) Revoke an authorization and order the drawbridge returned to operation when necessary.

(c) All drawbridges authorized to remain closed to navigation, under this section, must be maintained in operable condition.

(d) Authorization under this section does not:

(1) Authorize physical changes to the drawbridge structure, or

(2) Authorize removal of the operating machinery.

(e) Drawbridges authorized under this section to remain closed to navigation and to be untended are identified in subpart B of this part.

[USCG–2001–10881, 71 FR 70308, Dec. 4, 2006]

§ 117.40 Advance notice for drawbridge opening.

(a) Upon written request by the owner of a drawbridge, the District Commander may authorize a drawbridge to operate under an advance notice for opening. The drawbridge tender, after receiving the advance notice, must open the drawbridge at the requested time and allow for a reasonable delay in arrival of the vessel giving the advance notice.

(b) If the request is approved, a description of the advanced notice for the drawbridge will be added to subpart B of this part.

[USCG–2001–10881, 71 FR 70309, Dec. 4, 2006]

§ 117.41 Maintaining drawbridges in the fully open position.

(a) Drawbridges permanently maintained in the fully open to navigation position may discontinue drawtender service as long as the drawbridge remains fully open to navigation. The drawbridge must remain in the fully open position until drawtender service is restored.

§ 117.42

(b) If a drawbridge is normally maintained in the fully open to navigation position, but closes to navigation for the passage of pedestrian, vehicular, rail, or other traffic, the drawbridge must be tended unless:

(1) Special operating requirements are established in subpart B of this part for that drawbridge; or

(2) The drawbridge is remotely operated or automated.

[USCG-2001-10881, 71 FR 70309, Dec. 4, 2006]

§ 117.42 Remotely operated and automated drawbridges.

(a) Upon written request by the owner of a drawbridge, the District Commander may authorize a drawbridge to operate under an automated system or from a remote location.

(b) If the request is approved, a description of the full operation of the remotely operated or automated drawbridge will be added to subpart B of this part.

[USCG-2001-10881, 71 FR 70309, Dec. 4, 2006]

§ 117.47 Clearance gauges.

(a) Clearance gauges are required for drawbridges across navigable waters of the United States discharging into the Atlantic Ocean south of Delaware Bay (including the Lewes and Rehoboth Canal, DE) or into the Gulf of Mexico (including coastal waterways contiguous thereto and tributaries to such waterways and the Lower Atchafalaya River, LA), except the Mississippi River and its tributaries and outlets,

(b) Except for provisions in this part which specify otherwise for particular drawbridges, clearance gauges shall be designed, installed, and maintained according to the provisions of §118.160 of this chapter.

NOTE: Clearance gauge requirements, if any, for drawbridges other than those referred to in this section are listed in Subpart B under the appropriate bridge.

[CGD 82-025, 49 FR 17452, Apr. 24, 1984, as amended by CGD 84-022, 51 FR 16308, May 2, 1986; CGD 96-026, 61 FR 33664, June 28, 1996]

§ 117.49 Process of violations.

(a) Complaints of alleged violations under this part are submitted to the District Commander of the Coast

33 CFR Ch. I (7-1-12 Edition)

Guard District in which the drawbridge is located.

(b) Penalties for violations under this part are assessed and collected under Subpart 1.07 of Part 1 of this chapter.

Subpart B—Specific Requirements

§ 117.51 General.

The drawbridges in this subpart are listed by the state in which they are located and by the waterway they cross. Waterways are arranged alphabetically by state. The drawbridges listed under a waterway are generally arranged in order from the mouth of the waterway moving upstream. The drawbridges on the Atlantic Intracoastal Waterway are listed from north to south and on the Gulf Intracoastal Waterway from east to west.

[USCG-2001-10881, 71 FR 70309, Dec. 4, 2006]

§ 117.55 Posting of requirements.

(a) The owner of each drawbridge under this subpart, other than removable span bridges, must ensure that a sign summarizing the requirements in this subpart applicable to the drawbridge is posted both upstream and downstream of the drawbridge. The requirements to be posted need not include those in Subpart A or §§117.51 through 117.59 of this part.

(b) The signs shall be of sufficient size and so located as to be easily read at any time from an approaching vessel.

(c) If advance notice is required to open the draw, the signs shall also state the name, address, and telephone number of the person to be notified.

[CGD 82-025, 49 FR 17452, Apr. 24, 1984, as amended by USCG-2001-10881, 71 FR 70309, Dec. 4, 2006]

§ 117.59 Special requirements due to hazards.

For the duration of occurrences hazardous to safety or navigation, such as floods, freshets, and damage to the bridge or fender system, the District Commander may require the owner of an operational drawbridge listed in this subpart to have the bridge attended full time and open on signal.